



## Easy Tstat Instructions

### 1. Setting the time and day

- Press **Clk** using ▼▲ set hour.
- Press **Clk** using ▼▲ set min.
- Press **Clk** using ▼▲ set day.
- Press **Mode** to exit.

Note. The 12hr clock is used in the °F display setting.  
The 24hr clock is used in the °C display setting.



See instruction manual for more detailed instructions.

### 2. Setting the comfort and economy temperature set points.

- **Comfort** ☀  
Represents the temperature for when you are at home. (Morning, evening)
- To set the Comfort temperature ☀ select chosen temperature using ▼▲ buttons. Press and hold down the ☀ button until the icon is displayed. (Approx. 3 sec)
- **Economy** ☹  
Represents the temperature for when you are away, at work or at night.
- To set the Economy temperature ☹ select chosen temperature using ▼▲ Buttons. Press and hold down the ☹ button until the icon is displayed. (Approx. 3 sec)





### 3. Operating modes.

- **Manual mode.** 👆  
This mode maintains a constant floor temperature.
- To activate press **Mode** to display 👆 icon.
- Set desired temperature using ▼▲ or one of the pre-defined set point buttons ☀ or ☹.


- **Automatic mode. Auto**  
This mode executes your scheduled programming.
- To activate press **Mode** to display **Auto**.
- The ☀ or ☾ indicates which temperature setting is in use.
- The program number will also be displayed.
- **Standby**   
This mode is use to put the thermostat into the sleep mode when it is not required.
- To activate press **Mode** to display 


#### 4. Schedule Programming.


This is used when in the **Auto** mode.

<u>Program</u>	<u>Mode</u>	<u>Time</u>
 1	☀ Comfort	Wake-up Time
 2	☾ Economy	Leaving Time
 3	☀ Comfort	Return Time
 4	☾ Economy	Bed Time

- To Program your schedule.
- Press the **PGM** button to access the programming mode.

- Press **Pgm**  will be displayed. Set the time you wish the heaters to come on using the ▼ ▲ buttons.

- Press **Pgm**  will be displayed. Set the time you wish the heaters to come off using the ▼ ▲ buttons.

- Press **Pgm**  will be displayed. Set the time you wish the heaters to come back on using the ▼ ▲ buttons.



- Press **Pgm** will be displayed. Set the time that you wish the heaters to come off using the ▼ ▲ buttons.
- Once you have completed programming, press **Mode** to exit this function.

#### **5. Setting the number of programs per day.**

You can select the number of programs to be used each day .For Example you can set it to run all 4 programs or only 2(1<sup>st</sup> and 4<sup>th</sup>) or none (o)

- To change the amount of programs per Day press and hold **PGM** for 3 sec to access the advanced programming mode.
- Press **Pgm** until you get to the day you wish to modify.
- Using ▼ ▲ select number of programs per day.
- Press **Mode** to exit.

**For more detailed instructions see instruction manual enclosed with Tstat.**