

S-Series Master Wiring Centre

Overview

The S-Series Master Wiring Centre is designed to work with our 6iE, Element, tempo and S-Series range of thermostats and your heat source, i.e. boiler.

The wiring centre can control up to 4 zones and connects room thermostats to their corresponding actuators. Additional zones can be added using the S-Series 4 or 6 zone Slave units.

When the wiring centre is in operation, 230v output will switch relevant zone actuators, underfloor heating pump and valve on. Each zone is indicated by individual LED's on the wiring centre.

The wiring centre can be adapted either on a DIN rail or directly on a wall.

Technical Specifications



WIRING CENTRE - TECHNICAL SPECIFICATIONS

OPERATING VOLTAGE	220-240 V ac 50Hz
OPERATING TEMPERATURE	0 to 50 °C
MAX ACTUATORS	24 (Master 4 Zone + 2x Slave 4 Zone)
MAX ACTUATORS PER ZONE	4
ACTUATOR CONTACT	Triac
CIRCULATOR CONTACT	Relay (Max 8 amps)
VOLT FREE CONTACT	Relay (Max 16 amps)
DIMENSIONS	224 x 88 x 58 mm



Hydronic
Heating System

0345 345 2288

uk@warmup.com
www.warmup.co.uk

Warmup

The world's best-selling floor heating brand™