



WIRING DIAGRAM LEGEND		
	Live	L
	Earth	E
	Neutral	N
	Switched Live	SL
	Switched Live	SL
	Common	C
	Link Wire	

WARMUP PROGRAMMABLE THERMOSTAT TERMINAL LEGEND		
1	Fill Pilote (France)	F.P.
2	Supply - Live	L
3	Supply - Neutral	N
4	Load - Neutral	N
5	Load - Live	L
6	External Sensor	EXT
7	Floor Sensor	SEN
8	Floor Sensor	SEN

# Warmup

The world's best-selling floor heating brand™

WARMUP PLC, 702 & 704 Tudor Estate, Abbey Road, London, NW10 7UW  
Tel 0345 034 2288 Fax 0203 453 2299  
support@warmup.com www.warmup.co.uk

**TITLE**  
Wiring Diagram  
**WHS-C-B-MASTER01\_Volt Free Boiler\_**  
**Integrated Pump\_Programmable Thermostat**

DATE	DRAWN	REVISION
08.02.2017	GW	A

**PDF FILE**  
Warmup - WD - WHS-C-B-MASTER01 (Volt Free Boiler\_ Integrated Pump\_Programmable Thermostat) - 2017-02-08.pdf

Any electrical works undertaken should be completed by a suitable qualified competent electrician.  
Any interconnecting electrical components that form part of a hydronic system should be connected to a 3A power supply, with the whole system having a single point of isolation.

The Warmup word and associated logos are trade marks. © Warmup Plc. 2010 - Regd. TM Nos. 1257757, 4409926, 5265707. E & OE. Registered in England No. 2955213.  
All products must be earthed in accordance with current wiring regulations. **Some earth connections have been omitted for clarity.**