### Warmup – Primer





#### Overview

A ready to use, bond enhancing and solvent-free single component primer for the preparation of absorbent and non-absorbent floors and walls with or without surface heating. Ideal for use before laying Warmup Peel and Stick systems, levelling compounds and tile adhesives.

Suitable for use as a deep penetrating primer on absorbent surfaces.

# Suitable Substrates

Concrete	Metal	Epoxy Paints
Cement Screeds	Tile Backer Boards	Epoxy Moisture Barriers
Anhydrite Screeds	Terazzo floors	Water-Resistant Adhesive Residues
Magnesite Screeds	Natural Stone	MSP's
Levelling Compounds	Ceramic Tiles	Abraded Mastic asphalt
Timber	Vinyl	

» Not suitable for use on PUR pre-coatings or melamine faced boards.

» Contacting substrates, adhesives and compounds must be free of migrating elements.



# Recommended for use

We recommend the use of this primer with the following Warmup systems:

Electric	Hydronic
DCM-PRO	Nexxa 12
StickyMat	Total-16
StickyMat 3D	
StickyMat 12V	

# **Technical specifications**

Product Code	ACC-Primer	
Typical Consumption	Porous Substrate: 20m²/l (Diluted 1:1 with Water)	
	Non-Porous: 14m²/l (Undiluted)	
Application Temperature	15°C - 25°C	
Ideal Application Air Humidity	40% - 60%	
Drying Time	30 - 60 minutes (at 20°C and 65% relative humidity)	
	<ul> <li>» Higher humidity and/or lower temperatures delay drying</li> <li>» Lower humidity and/or higher temperatures accelerate drying</li> </ul>	
Density	1100 kg/m <sup>3</sup>	
Colour	Purple	
Shelf Life	12 Months in original container when kept out of direct sunlight and at temperatures between 10°C and 25°C, avoiding frost. Diluted product must be used on the day of dilution or discarded.	
Certification	EC1-PLUS GISCODE D1 TRG5 610 - Solvent-free	
Product Contains	2-methyl-2H-isothiazol-3-one and 1,2-benzisothiazol-3(2H)-one. Can cause allergic reactions. EU limit value for the product (Cat. A / h Wb): 30 g / l (2010). This product contains maximum 30 g / l VOC. In the event of a reaction, remove yourself or the affected person from the application area, seek medical advice and wash thoroughly with soap and water.	

## Contact

Warmup plc www.warmup.co.uk uk@warmup.com T: 0345 345 2288 F: 0345 345 2299

#### Warmup GmbH

www.warmupdeutschland.de de@warmup.com **T:** 04431 - 948 70 0 **F:** 04431 - 948 70 18

Warmup plc = 704 Tudor Estate = Abbey Road = London = NW10 7UW = UK Warmup GmbH = Ottostraße 3 = 27793 Wildeshausen = DE